Software FR-Configurator

The Setup Software FR-Configurator is a powerful tool for the operation of your frequency inverter.

The software runs under all versions of MS Windows and therefore allows the inverter operation via any conventional personal computer. Several frequency inverters can be set up, operated, and monitored simultaneously across a network or via a personal computer or laptop.

The Software FR-Configurator is designed for all frequency inverters of the 700-series.


The connection between personal computer and inverter is established either via an RS485 network or directly via an SC-FR PC adapter cable available separately. For the FR-E700/FR-A700 series a USB-connector is also available.




Benefits

- System settings
 Due to the network capabilities of the inverter up to 32 frequency inverters can be operated simultaneously.
- Parameter settings
 By means of overall and function related overviews different parameters can be adjusted easily.
- Display functions
 The comprehensible display functions enable data, analog, oscillograph, and alarm displays.
- Diagnostics
 The analysis of the inverter status provides a thorough error correction.
- Test operation
 The test operation provides a simulation of the operation and adjustment via the auto-tuning function.
- File management
 Parameters can be saved on the personal computer and printed out.
- Help
 The extensive online help provides support concerning all questions regarding settings and operation.

Parameter setting



Display and monitor



Test operation

